










Lynlås- og skydertyper efter funktion Types of Zippers and Sliders by Function



BASISLYNLÅSE BASIC SLIDERS

<p>Non-lock skyder <i>Non-Lock Slider</i></p> <p>Vedhængen låser ikke i nogen stilling på skyderhuset. Ingen låsemekanisme. <i>The pull-tab doesn't lock at any position of the body. No locking mechanism.</i></p>  <p>DF</p>	<p>Automatisk skyder <i>Automatic Slider</i></p> <p>Låsen låser automatisk, når vedhængen ikke påvirkes. <i>The lock automatically locks when no force is applied to the pull tab.</i></p>  <p>DA</p>	<p>Semi-automatisk skyder <i>Semi-automatic Slider</i></p> <p>Vedhængen låser, når den trækkes nedad. Vedhængen åbner, når den trækkes opad. <i>The pull-tab locks when lowered. The pull-tab unlocks when raised.</i></p>  <p>DS</p>
<p>Jeansskyder <i>Jeans Slider</i></p> <p>Semi-automatisk skyder til jeans. <i>Semi-automatic slider for jeans.</i></p>  <p>GSN8</p>	<p>Pin-lock-skyder <i>Pin Lock Slider</i></p> <p>Stifter på vedhængen påvirker elementerne og låser. <i>Pins on the pull tab work on the elements and lock.</i></p>  <p>DP</p>	<p>Dobbelt vedhæng <i>Double Pull</i></p> <p>Åbner eller lukker både forfra og bagfra. (Auto-lock "DX", non-lock "DW", notch-lock "DD") <i>Opens or closes from either front or back. (Automatic "DX", Non-Lock "DW", Notch Lock "DD")</i></p>  <p>DX/DW/DD</p>
<p>Vendbar skyder <i>Reversible Slider</i></p> <p>Vedhængen bevæger sig ad en roterende skinne. Lynlåsen åbnes og lukkes enten forfra eller bagfra. (Automatisk) <i>The puller moves along a rotating rail. The zipper opens or closes from either front or back. (Automatic)</i></p>  <p>DU</p>	<p>Plastikskyder <i>Plastic Slider</i></p> <p>Låsen er af metal. (Non-lock, Automatisk) <i>The lock is made of metal. (Non-lock, Automatic)</i></p>  <p>TA/TX</p>	