


## Lynlås- og skydertyper efter funktion

### Types of Zippers and Sliders by Function



#### BASISSKYDERE BASIC SLIDERS

<b>Non-lock skyder</b> <i>Non-Lock Slider</i>	DF	<b>Automatisk skyder</b> <i>Automatic Slider</i>	DA	<b>Semi-automatisk skyder</b> <i>Semi-automatic Slider</i>	DS
Vedhænget låser ikke i nogen stilling på skyderhuset. Ingen låsemekanisme. <i>The pull-tab doesn't lock at any position of the body. No locking mechanism.</i>		Låsen låser automatisk, når vedhænget ikke påvirkes. <i>The lock automatically locks when no force is applied to the pull tab.</i>		Vedhænget låser, når det trækkes nedad. Vedhænget åbner, når det trækkes opad. <i>The pull-tab locks when lowered. The pull-tab unlocks when raised.</i>	
<b>Jeansskyder</b> <i>Jeans Slider</i>	GSN8	<b>Pin-lock-skyder</b> <i>Pin Lock Slider</i>	DP	<b>Dobbelt vedhæng</b> <i>Double Pull</i>	DX/DW/DD
Semi-automatisk skyder til jeans. <i>Semi-automatic slider for jeans.</i>		Stifter på vedhænget påvirker elementerne og låser. <i>Pins on the pull tab work on the elements and lock.</i>		Åbner eller lukker både forfra og bagfra. (Auto-lock "DX", non-lock "DW", notch-lock "DD") <i>Opens or closes from either front or back. (Automatic "DX", Non-Lock "DW", Notch Lock "DD")</i>	
<b>Vendbar skyder</b> <i>Reversible Slider</i>	DU	<b>Plastikskyder</b> <i>Plastic Slider</i>	TA/TX		
Vedhænget bevæger sig ad en roterende skinne. Lynlåsen åbnes og lukkes enten forfra eller bagfra. (Automatisk) <i>The puller moves along a rotating rail. The zipper opens or closes from either front or back. (Automatic)</i>		Låsen er af metal. (Non-lock, Automatisk) <i>The lock is made of metal. (Non-lock, Automatic)</i>			